

**ROKAE** 罗石

**CR35-45/1.9C**

Hardware Installation Manual



人类生产生活的得力伙伴

A Partner You can Rely on in Production



# CR35-45/1.9C

## Hardware Installation Manual

Document ID: **DOC-00002072**

Version: [Status]

Copyright © ROKAE 2025-2026. All rights reserved.

Contents in the Manual are subject to change without notice. We assume no responsibility for any errors that may appear in the Manual.

We hope you can understand that in no event shall we be liable for incidental or consequential damages arising from the use of the Manual and the products described herein.

We cannot foresee all possible dangers and consequences. Therefore, the Manual cannot warn the user of all possible hazards.

No part of the Manual may be reproduced in any form.

If you find the contents of the Manual wrong or in need of improvement or supplement, please contact us for correction.

The original language of the Manual is Chinese, and all other language versions are translated from the Chinese version.

Copyright © ROKAE 2025-2026. All rights reserved.

ROKAE (Shandong) Intelligent Technology Co., Ltd.

Shandong, China

## Contents

1 Manual Overview .....	1
1.1 About the Manual .....	1
1.2 Target group .....	1
1.3 How to read the Manual .....	1
1.4 Illustrations in the Manual .....	1
1.5 Related product documents .....	1
1.6 Contact .....	1
2 Safety .....	2
2.1 Introduction .....	2
2.1.1 Safety responsibilities .....	2
2.1.2 Intended use .....	2
2.2 Safety notice .....	3
2.3 Safety protection device .....	3
2.3.1 Emergency stop .....	3
2.3.2 Enabling device .....	3
2.4 Safety precautions .....	4
2.4.1 Operator safety .....	4
2.4.2 Safety precautions for operating the Teach Pendant .....	5
2.4.3 Recovering from emergency stops .....	6
2.4.4 Safety precautions in manual mode .....	6
2.4.5 Safety precautions in automatic mode .....	6
2.4.6 Safe handling of fire accidents .....	7
2.4.7 Safe handling of electric shock accidents .....	8
2.5 Personnel and work requirements .....	8
2.5.1 Definition of personnel .....	8
2.5.2 Personnel requirements .....	9
2.5.3 Work requirements .....	10
2.6 Safety training .....	11

2.6.1 Overview .....	11
2.6.2 Personnel safety .....	11
2.7 Pre-use assessment .....	13
<b>3 Product Overview .....</b>	<b>14</b>
3.1 System structure .....	14
3.2 Manipulator .....	14
3.3 Teach Pendant .....	15
3.3.1 Overview of Teach Pendant .....	15
3.3.2 Composition and description of Teach Pendant .....	16
3.3.3 Holding of the Teach Pendant .....	16
3.4 Control cab .....	17
3.4.1 Overview of control cab .....	17
3.4.2 Composition of control cab .....	17
3.5 Symbols and labels .....	18
<b>4 Technical Specifications .....</b>	<b>19</b>
4.1 Manipulator .....	19
4.1.1 Basic parameters .....	19
4.1.2 Working space .....	20
4.1.3 Allowable load .....	21
4.2 Teach Pendant .....	24
4.3 Control cab .....	24
<b>5 Unpacking and Installation .....</b>	<b>26</b>
5.1 Installation flow chart .....	26
5.2 Environmental conditions .....	26
5.3 Unpacking .....	27
5.4 Transportation and handling .....	29
5.4.1 Robot angle and force application points during transportation .....	29
5.4.2 Handling .....	30
5.5 Installation .....	32

5.5.1 Inspection before installation .....	32
5.5.2 Installation of robot and control cab .....	32
5.5.3 Flange .....	35
<b>6 Electrical connection .....</b>	<b>36</b>
6.1 Control cab port .....	36
6.1.1 Panel port .....	36
6.1.2 Internal port .....	37
6.2 Band-type brake release .....	45
6.3 Description of EOAT I/O ports .....	46
6.3.1 Special-purpose EOAT I/O .....	47
6.3.2 EOAT power output .....	47
6.3.3 EOAT digital outputs .....	48
6.3.4 EOAT digital inputs .....	49
6.3.5 EOAT analog inputs .....	50
6.3.6 EOAT communication .....	50
6.4 Connection system .....	51
6.4.1 Connection of the Teach Pendant .....	52
6.4.2 Connection of the manipulator .....	52
6.4.3 Connection of the control cab power supply .....	53
6.4.4 Custom wiring .....	53
6.4.5 Grounding instructions .....	55
<b>7 Quick Operation .....</b>	<b>56</b>
7.1 Power on .....	56
7.2 Confirmation of the emergency stop .....	56
7.3 Programming and usage .....	56
7.4 Application configuration of general-purpose digital I/O port .....	57
<b>8 Maintenance .....</b>	<b>59</b>
8.1 Introduction .....	59
8.2 Maintenance safety .....	59

8.3 Maintenance schedule .....	59
8.4 Inspection .....	59
8.5 Lubrication .....	60
8.5.1 Oil refilling mode .....	60
8.5.2 Reducer lubrication .....	61
8.5.3 Axis 1 reducer lubrication .....	62
8.5.4 Axis 2 reducer lubrication .....	62
8.6 Battery replacement .....	63
8.6.1 Safety risks with batteries .....	63
8.6.2 Battery replacement .....	63
8.7 Cleaning .....	65
9 Zero calibration .....	66
9.1 What is a mechanical zero? .....	66
9.2 What is zero calibration? .....	66
9.3 When is zero calibration required? .....	66
9.4 Zero calibration procedures .....	66
10 Safety Manual .....	68
10.1 Stop time and stop distance .....	68
10.2 Test data .....	68
11 Decommissioning .....	73
11.1 Robot decommissioning .....	73
11.2 Recycling .....	73
12 Revision history .....	74

# 1 Manual Overview

## 1.1 About the Manual

Thank you for choosing ROKAE robot system.

The Manual contains the following instructions for the correct installation and use of the robot:

- Mechanical and electrical installation of the robot.
- Maintenance and calibration of the robot.

Please read the Manual and other related manuals carefully before installing and using the robot system.

After reading, keep it properly for future reference.

## 1.2 Target group

The Manual is intended for:

- Installation personnel
- Maintenance personnel

Please ensure that the above personnel have the necessary knowledge of mechanical and electrical installation and maintenance, and have received our training.

## 1.3 How to read the Manual

The Manual includes a separate safety section that must be read through before proceeding with any installation or maintenance procedures.

## 1.4 Illustrations in the Manual

Due to product upgrades or other reasons, some figures in the Manual may differ from the actual products. However, the operating procedures are correct.

Also, figures from other models may be used to describe some general information.

## 1.5 Related product documents

This document is CR35-45/1.9C the manual for the robot and is intended to be used with the following documents:

- *xCore Robot Control System User Manual*

## 1.6 Contact

For information about the maintenance and repair of the robot, please contact our after-sales department or the local dealer.

Get the following information ready before contacting us:

- Robot model/serial number
- Software name/version
- Problems with the system

## 2 Safety

### 2.1 Introduction

This section describes CR35-45/1.9C of CR35-45/1.9C CR35-45/1.9C for the first time. The contents related to the design and installation of the external safety protection devices of the robot are not covered in this chapter. You can contact your system integrator to obtain such information.

#### 2.1.1 Safety responsibilities

ROKAE is dedicated to but not liable for providing reliable safety information. Even if all safety instructions are followed, there is no guarantee that CR35-45/1.9C robots will not cause any personal injury or property damage.

In addition to the safety section, the Manual contains further safety instructions.

#### 2.1.2 Intended use

CR35-45/1.9C robots shall be used in accordance with local laws and regulations, and shall not be used for any purpose that violates such laws and regulations.

Using the robots in compliance with instructions also means observing the instructions in the manual of each component, including the operation, installation, and maintenance instructions.

The following uses that go against the instructions are prohibited:

- Use in human and animal transportation
- Use in potentially explosive environments
- Use in flammable environments
- Use outside the permissible limits
- Use underground

CR35-45/1.9C robots are flexible collaborative robots intended to handle EOAT/end effectors and fixtures or to process or transfer components or products. CR35-45/1.9C robots have special safety-related features, which are purposely designed to enable collaborative operation, where the robot system operates without fences and/or together with a human.

Collaborative operation is only intended for non-hazardous applications, where the complete application, including the EOAT/end effectors, workpieces, obstacles, and other machines, has no any significant hazards according to the risk assessment of the specific application.

Any purpose deviating from the intended use is deemed to be impermissible misuse, including but not limited to:

This includes, but is not limited to:

- Use in potentially explosive environments

- Use in medical and life-critical applications
- Use without a risk assessment
- Use outside the stated specifications
- Use as a climbing aid
- Use outside the permissible operating parameters

## 2.2 Safety notice

- A risk assessment must be conducted before operating or controlling the robot, and the robot must be used according to the safety instructions described in the Manual.
- If you are unsure about the risks during the use of the robot, please contact ROKAE Technical Support. However, problems arising from non-intended use are not covered by our support.

## 2.3 Safety protection device

### 2.3.1 Emergency stop

Emergency stop is given the highest priority in the robot system. Pressing the emergency stop button will trigger the emergency stop. Then, all the functions will be frozen immediately, the robot will stop running, and the power of each joint will be cut off. The control system will be switched into the emergency stop state, which will be maintained before releasing the emergency stop button manually.

To resume the operation, it is required to release the emergency stop button first and then press the reset button on HMI for the motor of each joint to execute the power-on command.

The emergency stop button is located in the upper right corner of the Teach Pendant, as shown in 3.3.2.



#### Notes

Emergency stop shall not be used for normal stops. Otherwise, extra and unnecessary wear may be caused to the brake and transmission system, which will eventually reduce the robot's service life.

There are two types of stops for robots according to ISO 13850 and IEC 60204 safety standards:

- STOP0: The motor power is switched off and the brakes are engaged.
- STOP1: The robot comes to a controlled stop. Then the motor power is switched off and the brakes are engaged.


After the emergency stop button on the Teach Pendant is pressed, the stop is enabled in type of STOP0.

### 2.3.2 Enabling device

The enabling device is a special switch with two contacts and three positions, so it is also

called a three-position enabling switch (hereinafter referred to as "enabling switch"). It is used to power on/off the joints in Manual mode to enable robot motions.

The motor power is switched on only when the enabling switch is pressed and kept in the middle so that the robot is in a state ready for motion.



The enabling switch is located on the back of the Teach Pendant, as shown in 3.3.2.



#### Notes

When the enabling switch is pressed and held in the middle position in Manual mode, the robot will be powered on and enabled, the system will enter the Motor On state, and you can jog the robot or execute a program. The robot will be powered off, and the system will return to the Motor Off state when the switch is released or pressed all the way down.

To ensure the safe use of the robot, the following requirements must be observed:

The enabling switch shall function properly in any circumstances.

The enabling switch shall be released immediately when no robot motion is required during programming or debugging.

Any person who enters the robot's working space must carry a handheld enabling device to prevent others from starting the robot without the knowledge of the involved personnel.



#### Warning

It is strictly prohibited to use external devices to hold the enabling switch in the middle position.

## 2.4 Safety precautions

### 2.4.1 Operator safety

A few simple principles shall be followed in order to operate the robot safely:

- Always operate the robot in Manual mode if personnel are inside the safeguarded

space.

- Always bring the handheld emergency stop device along when you enter the safeguarded space so that robot control is in your hands.
- Watch out for rotating or moving tools installed on the robot. Make sure those tools are stopped before you approach the robot.
- Watch out for grippers and objects gripped. If the gripper is opened, the workpiece could fall and cause personal injury or equipment damage. The gripper can be very powerful and can also cause injuries if not operated safely.

## 2.4.2 Safety precautions for operating the Teach Pendant

### 2.4.2.1 Safe storage of the Teach Pendant

The Teach Pendant no longer used shall be properly stored in a place where is far away from the robot workstation, in order to prevent the operator from mistakenly believing that this Teach Pendant is still connected to the robot and attempting to use it to stop the robot in case of danger.

### 2.4.2.2 Teach Pendant cable

The Teach Pendant and control cab are connected through a Teach Pendant cable. The following provisions shall be observed when using the Teach Pendant in order to avoid personal injury or equipment damage:

- Make sure that the working personnel does not stumble over the Teach Pendant cable so as to avoid dropping the Teach Pendant or making personnel fall.
- Don't squeeze the Teach Pendant cable, otherwise, its internal cores may be damaged.
- Don't put the Teach Pendant cable on the edge of the sharp objects, otherwise, the cable sheath may be damaged.
- Make sure that the bending radius of the Teach Pendant cable is greater than 80 mm, otherwise, the cable may be damaged.

### 2.4.2.3 Permission of using the Teach Pendant

Generally, only those who have completed safety training and basic operation training can have permission to use the Teach Pendant. The user permissions for operating the Teach Pendant interface shall also be distinguished to ensure that the debugging personnel and maintenance personnel can use the Teach Pendant correctly and reasonably according to their work.

The control system is built-in with three user levels, namely Operator, Teacher, Programmer, Admin, and God, with the operation permissions ranking from low to high. Switching from a low-privileged user to a high-privileged user requires a password. Conversely, it is not required. A high-privileged user can modify the password of a same- or lower-privileged user. The password of an Operator-level user cannot be modified.

#### 2.4.2.4 No Teach Pendant mode

When the No Teach Pendant mode is selected for the control system, special attention must be paid to safety during debugging and programming. An emergency stop button must be installed or placed within the reach of the operator and the signal of the emergency stop button must be routed into the safe I/O port of the robot system so that the person can protect the safety of himself/herself and the equipment by pressing the emergency stop button promptly in case of emergencies.

#### 2.4.3 Recovering from emergency stops

##### 2.4.3.1 Explanation

In case of an emergency stop, a reset is required to return to normal operation. The reset procedure is simple but important. It ensures that the robot system is prevented from returning to production in a hazardous condition.

##### 2.4.3.2 Emergency stop button and reset

The emergency stop button is located in the upper right corner of the Teach Pendant. It has a latching feature that must be manually released in order to remove the emergency stop condition of the robot. This can be done by rotating the button as marked.

#### 2.4.4 Safety precautions in manual mode

##### 2.4.4.1 About the manual mode

In Manual mode, the robot's movement is under manual control. You can jog the robot or execute a program only when the enabling switch is held in the middle position. The enabling switch is located on the handle of the Teach Pendant.

The manual mode is used during the programming and debugging of the robot, as well as the commissioning of the workstation.

##### 2.4.4.2 Speed limit in manual mode

In Manual mode, the speed of the robot's end effector is limited to below 250 mm/s, that is, the maximum speed of the robot will not exceed 250 mm/s whether you jog the robot or execute a program, regardless of the speed set in the program.

##### 2.4.4.3 Bypassing external safety signals

In Manual mode, signals of external safety devices such as the safety gate and safety grating will be bypassed. This means that the emergency stop will not be triggered in Manual mode even if the safety gate is open, which facilitates the debugging.

#### 2.4.5 Safety precautions in automatic mode

##### 2.4.5.1 About the automatic mode

The Automatic mode is used for running the robot program in production.

In automatic mode, the enabling switch will be bypassed so that the robot can run

automatically without manual intervention.



#### DANGER

In Automatic mode, the robot moves at the speed set in the program, which is up to 3.5 m/s for the end effector. In this mode, personnel must not enter the working space of the robot to avoid personal injury.

#### 2.4.5.2 Enabling external safety signals

External safety devices such as the safety gate and safety grating will be enabled in Automatic mode. Opening the safety gate will trigger an emergency stop.

#### 2.4.5.3 Safe troubleshooting in production

In most cases, the robot is part of the production line. Therefore, the impact of a robot fault may go beyond the workstation itself. Likewise, problems with other parts of the production line may also impact the workstation. For this reason, a remedy plan shall be prepared by personnel who are familiar with the entire production line to improve safety.

- Pay attention to other running devices around the robot.

For example, a robot on the production line grabs workpieces from the conveyor belt. When the robot has a fault, the robot maintenance personnel shall consider additional safety measures for working beside the moving conveyor belt to ensure uninterrupted production while the robot is under repair.

- Pay attention to other devices that interact with the robot.

For another example, when removing a welding robot from the production line for routine maintenance, the robot supplying materials to it must also be stopped to avoid personal injury.

#### 2.4.6 Safe handling of fire accidents

##### 2.4.6.1 Handling of mild fires

It is required to keep calm when a fire hazard is imminent or has not yet begun to spread. You can use on-site fire-extinguishing devices to put out the flame. It is strictly prohibited to use water to put out a fire caused by a short-circuit fault.



#### Warning

The fire-extinguishing device on the working space of the robot shall be supplied by the user, and the user shall choose an appropriate fire-extinguishing device according to the actual situations. For fire with the controller, a carbon dioxide (CO2) fire extinguisher is required.

##### 2.4.6.2 Handling of severe fires

If the fire has spread beyond control, the workers on site shall notify other workers immediately to give up their personal belongings and evacuate immediately through

emergency exits rather than try to put out the fire. Do not use an elevator, and inform the fire department during evacuation.

If a person's clothing catches fire, prevent him/her from running but let him/her lie flat on the ground immediately. Put out the fire using clothes or other suitable items and methods.

## 2.4.7 Safe handling of electric shock accidents

### 2.4.7.1 Handling of electric shocks

When someone gets an electric shock, it is required to keep calm and cut off the power supply immediately. Appropriate methods and measures shall be adopted without hesitation according to the site conditions:

- If the power switch or button is very near to the location of the electric shock, switch it off to cut off the power supply.
- If the power switch or button is far away from the location of the electric shock, use insulated pliers or ax, knife, and shovel with dry wooden handles to cut off live wires on the mains' side (power supply), and keep the separated wire from contacting with the human body.
- If the conducting wire is over or under the body of the injured, use a dry stick, board, bamboo pole, or other tools with insulated handles (by gripping the insulated handle) to remove the wire. Do not use metal bar or wet object to avoid the rescuer from also getting an electric shock.



#### Warning

The rescuer shall not be in direct contact with the electrically shocked person. Otherwise, they may also get an electric shock!

### 2.4.7.2 Treatment of the injured after being separated from the power source

- If the injured is conscious, make him/her lie on the back and watch him/her out to prevent from standing or walking for the time being.
- If the injured person is unconscious, make him/her lie on the back to keep the airway open. Call the injured or pat him/her on the shoulder at an interval of 5s to judge if he/she loses consciousness. Do not call the victim by shaking his/her head. Meanwhile, contact the hospital as soon as possible.
- If the injured loses consciousness, confirm his/her respiratory conditions and heartbeat within 10s. If neither breath nor arterial pulse is sensed, the injured may have a cardiac arrest. Then, give him/her immediate first aid treatment by cardiopulmonary resuscitation.

## 2.5 Personnel and work requirements

### 2.5.1 Definition of personnel

There are three types of personnel:

- Operators

The operators can switch on/off the robot power supply and start robot programs through the Teach Pendant or other interfaces.

- Debugging personnel

The debugging personnel can conduct robot operations, enter into the safeguarded space, and perform operations such as setting, teaching, and programming on the robot.

- Maintenance personnel

The maintenance personnel can conduct robot operations, enter the safeguarded space, perform operations such as setting and teaching on the robot, as well as adjust and repair the robot.



Warning

The debugging and maintenance personnel who can enter the safeguarded space must accept and pass professional robot training in advance.



Warning

When performing robot operations, programming, and maintenance, personnel must pay attention to safety and wear necessary protective equipment, including work clothes, safety shoes, and safety helmets suitable for the work according to the actual conditions.

## 2.5.2 Personnel requirements

### 2.5.2.1 Operator requirements

The operator shall meet the following requirements:

- The age of the operator shall fall within the age range specified in local employment laws.
- The operator shall be in good physical condition. A good physical condition means good vision (glasses and contact lenses are allowed), good hearing, and good coordination ability. The operator may not intake substances that may reduce their mental level (such as medicines, alcohol, and drugs) during work.
- The operator shall understand applicable local safety regulations, such as the work safety and health regulations and the industrial accident prevention regulations.

### 2.5.2.2 Debugging personnel requirements

The debugging personnel shall meet the criteria of operating personnel. In addition, the debugging personnel shall also meet the following conditions:

- The debugging personnel shall have basic technical knowledge, understand the technical documents and drawings related to the robot, and be able to complete their tasks according to relevant documents.

- The debugging personnel must be very familiar with the robot system and be able to reasonably achieve the purpose by operating the robot according to actual needs.

### 2.5.2.3 Maintenance personnel requirements

In addition to compliance with the operator requirements, the maintenance personnel shall also have some other expertise (such as electrical, mechanical, and pneumatic) and be able to complete their tasks according to relevant documents.

### 2.5.3 Work requirements

#### 2.5.3.1 Safety requirements for installation and operation

- Handle and install the robot equipment through the methods described in our manual. Otherwise, the robot may fall due to misoperation, thus leading to personal injury and death or equipment damage.
- When the robot equipment is put into use for the first time after installation, run it at low velocity first and then gradually increase the velocity rather than running at high velocity from the start.
- Note that by default, program and system information (including variables) is stored in the storage device at the control cab. In order to prevent data loss caused by accidents, it is recommended that the user make data backups regularly.

#### 2.5.3.2 Safety requirements for debugging

Debugging shall be carried out outside the safeguarded space as much as possible. When debugging must be carried out inside the safeguarded space, special attention shall be given to the following:

- Carefully check the condition of the safeguarded space and enter into it only after confirming no danger exists.
- Confirm the positions of all debugging personnel inside the safeguarded space.
- Confirm the status of the entire system before proceeding with the work.
- Make sure that the emergency stop button can be pressed whenever necessary.
- Run the robot at low velocity.

When the above debugging is finished, the debugging personnel must stay outside the safeguarded space.

#### 2.5.3.3 Safety requirements for maintenance

- Carefully check the condition of the safeguarded space and enter into it only after confirming no danger exists.
- Confirm the positions of all maintenance personnel inside the safeguarded space.
- When the power supply is switched on, some maintenance operations may pose the danger of electric shock. Therefore, switch off the power supply of the robot equipment and system before carrying out the maintenance.
- During the maintenance, prevent other personnel from switching on the power supply

accidentally.

- To avoid unnecessary personal injury or adverse impact on the equipment, do not place any part of your body on any position of the robot equipment during the operation.
- Provide appropriate lighting during the maintenance.
- In case of part replacement, make sure to use a part specified by ROKAE. Otherwise, the robot equipment may be damaged.
- Install the parts removed during the replacement (such as screws) properly to their original positions. If you find the parts not enough or redundant, confirm again and make sure to install them correctly.

## 2.6 Safety training

### 2.6.1 Overview

The on-site operator, debugging personnel, and maintenance personnel must accept formal robot safety and operation training and pass the exams before they can perform operation, debugging, and maintenance on the robot. Operating, debugging, or maintaining robots by non-professional personnel or personnel who failed during the training is prohibited in order to avoid severe personal injury and damage to the robot equipment.

All the personnel of the equipment shall:

- Check the current condition of the equipment and ensure that no failure is present before performing operation and debugging on the robot equipment.
- Minimize life and property losses by choosing the safest method to handle emergency incidents as they occur.
- Fully understand relevant documents and work on the equipment according to the requirements of documents.

### 2.6.2 Personnel safety

The following general precautions must be noted to ensure personnel safety:

- When the equipment is running, even if the robot seems to have stopped, it may be waiting for the start signal to run. At this time, the equipment shall also be deemed as in the operating state.
- All peripheral equipment shall be well grounded.
- Peripheral equipment shall be installed outside the working range of the robot.
- The motion range of the robot equipment shall be marked by drawing lines on the floor or other means.

#### 2.6.2.1 Safety of operators

To ensure the safety of operators:

- Operate the robot outside the safeguarded space.
- Set up a protective fence or safety door in order to prevent irrelevant personnel from

entering the safeguarded space.

- Switch off the power supply or press the emergency stop button in case of no operation on the robot.
- Install the emergency stop button within reach of the operator.

#### 2.6.2.2 Safety of debugging personnel

During the debugging, you need to enter into the working range of the robot under some circumstances. To ensure the safety of debugging personnel:

- Make sure that the equipment is safe before debugging.
- Check the position and status of the safety devices (such as the emergency stop button) in advance.
- Prevent other personnel from entering the working range of the robot.
- Before starting the robot, make sure that there is no personnel in the working range of the robot.

When the debugging is finished, execute a test run according to the following procedures:

- At low velocity, execute the program one step after another for at least one cycle to confirm that everything is normal.
- At low velocity, execute the program continuously for at least one cycle to confirm that everything is normal.
- At the actual running velocity, execute the program continuously for at least one cycle to confirm that everything is normal.

#### 2.6.2.3 Safety of maintenance personnel

To ensure the safety of maintenance personnel:

- Make sure that the peripheral equipment is safe before maintenance.
- Switch off the equipment power supply before maintenance. Lock the main circuit breaker using a lock as necessary in order to prevent other personnel from switching on the power supply accidentally.
- When you have to enter into the working range of the robot while the power is on, press the emergency stop button before entering. Put up a "Repairs in Progress" sign in order to prevent other personnel from operating the equipment accidentally.
- Do not enter the working range of the robot while it is moving.
- Do not execute the automatic running of the program when there is other personnel within the working range of the robot.
- During maintenance, assign a person who is familiar with the robot system and is able to sense dangers near the equipment to press the emergency stop button in case of an emergency.
- During component replacement or reassembly, avoid the adhesion or inclusion of foreign objects.
- For maintaining the interior of the robot, if it is necessary to touch the power supply

unit or printed circuit board, switch off the power supply of the robot in advance to prevent electric shock.

## 2.7 Pre-use assessment


The following tests must be conducted before using the robot for the first time or after making any modifications to verify that all safety inputs and outputs are correct and properly connected, and check whether all connected safety inputs and outputs are functioning properly, including:

- Test whether the emergency stop button on the Teach Pendant can be enabled to stop the robot and engage the brakes.
- Test whether the robot can be switched between Manual and Automatic modes.
- Test whether the motion can be enabled in Manual mode only with the enabling switch of the Teach Pendant pressed and the robot is under deceleration control.

## 3 Product Overview

### 3.1 System structure

CR35-45/1.9C robot is a new flexible collaborative robot that boosts increased industrial productivity with highly sensitive force sensing. It consists of the manipulator, control cab, Teach Pendant, signal relay cable, power relay cable, power cable, control system software, etc.



S/N	Name
1	Manipulator
2	Control cab
3	Teach Pendant
4	Signal relay cable
5	Power relay cable
6	Controller power cable

### 3.2 Manipulator


CR35-45/1.9C collaborative manipulator features 6 degrees of freedom, that is, 6 joints or axes. The definitions of axis rotation directions and frames are described below:

**Base frame:** The -X axis refers to the outgoing cable direction of the base, and the +Z axis refers to an upward direction perpendicular to the mounting surface. The Y axis is determined by the right-hand rule.

**Flange frame:** When the robot is in the zero orientation, the +Z axis refers to an outward direction perpendicular to the flange surface, and the +X axis refers to the direction

opposite to outgoing cable direction of the base. The Y axis is determined by the right-hand rule.

Rotation axis directions: When the axes are in the zero position, the A1, A4, and A6 perform forward rotation in the +Z direction of the base frame, the A2 performs forward rotation in the +Y direction, and the A3 and A5 perform forward rotation in the -Y direction.




### 3.3 Teach Pendant

#### 3.3.1 Overview of Teach Pendant

The Teach Pendant is an embedded handheld device integrated with complete hardware and software. It is available for performing all robot-related functions, including programming and debugging, viewing system status, and setting system parameters.


The robot system is equipped with a Teach Pendant called xPad2, which is well-designed, reliable, and easy to use. Skilled use of xPad2 will greatly improve the efficiency of the robot.



### 3.3.2 Composition and description of Teach Pendant

The xPad2 Teach Pendant consists of the following components:


- Capacitive touch screen
- Button
- Emergency stop button
- Three-position enabling switch
- USB port, etc.



S/N	Description
A	Emergency stop button: used to trigger an emergency stop in case of danger.
B	Jog buttons: refer to 12 buttons in 6 groups corresponding to the robot's 6 joints or 6 DOF in Cartesian space.
C	Three-position enabling switch: used to enable robot motion in the Manual mode.
D	Function buttons: used to scroll between functions displayed on the touch screen.
E	USB port: used for connecting the USB drive and protected with a rubber cover.

### 3.3.3 Holding of the Teach Pendant


The Teach Pendant is usually used for handheld operation. Right-hand users are required to hold the Teach Pendant with left hand and operate the buttons and touch screen with right hand, as shown in the figure below:



## 3.4 Control cab

### 3.4.1 Overview of control cab


The main components of the robot control system are installed in a xMate Control Cab Mix (MCCM), as shown in the figure below:



### 3.4.2 Composition of control cab

The MCCM is designed to accommodate all the necessary components for controlling the robot's movements, as shown in 6.1.

### 3.5 Symbols and labels



S/N	Item
1	Arm body logo
2	Manipulator nameplate
3	Control cab logo
4	Control cab nameplate

## 4 Technical Specifications

This section describes the specifications CR35-45/1.9C collaborative robots.

### 4.1 Manipulator

#### 4.1.1 Basic parameters

Item	Item	
Product Name	CR35-45/1.9C	
Number of axes	6	
Maximum reach	1947mm	
Repeated positioning accuracy	±0.05mm	
Maximum payload	45kg	
Range of motion	Axis 1	±360°
	Axis 2	±360°
	Axis 3	±166°
	Axis 4	±360°
	Axis 5	±360°
	Axis 6	±360°
Maximum speed	Axis 1	163°/s
	Axis 2	163°/s
	Axis 3	135°/s
	Axis 4	155°/s
	Axis 5	199°/s
	Axis 6	228°/s
Operating temperature	0°C ~ +50°C	
Storage temperature	-10°C ~ +55°C	
Maximum relative operating/storage humidity	93%, non-condensing, non-frost	
IP rating	IP67	
Mounting method	At any angle	
Weight	Approx. 170 kg	
Noise (mean)	≤70dB(A)	




#### Warning

When the equipment leaves the factory, the motion limit of each axis does not exceed ±180° by default. The user can modify the range of motion of each axis according to the actual situations and this manual, provided that:

- The user is clearly aware of the range of motion of each axis described in this manual.
- The user ensures that the modified limit does not exceed the range of motion described in this manual.
- The user comprehensively considers relevant factors such as robot installation modes, EOAT characteristics, surrounding environment, and ensures that the modified limit and the programming will not pose danger of collision.
- If the user changes the limit and brings it into effect, it means that the user confirms that the above rules are followed properly, and agrees that all consequences arising from the failure to follow the above rules properly will be borne by the user.

#### 4.1.2 Working space

CR35-45/1.9C workspace diagram – the space went by the wrist reference point (the intersection of axes 4 and 5), as shown in the figure below.



#### 4.1.3 Allowable load



##### Warning

It is very important to always define the actual load correctly and calibrate the payload of the robot. Otherwise, it may result in robot overload.

If incorrect load and/or load other than those specified in the load diagram are used, the following components may be damaged due to overload:

- Motor
- Reducer
- Mechanical structure

All loads installed on the robot, including the total weight of the end effector, fixture,

and workpiece, shall be less than the maximum payload of the robot.

Robots operating with incorrect load and/or load other than those specified in the load diagram will not be covered by the robot warranty.

#### 4.1.3.1 Allowable wrist torque and inertia

To fully leverage the robots' performance and protect the robot from any failure or damage caused by overload, the payload installed on the robot must not exceed the allowable torque and inertia. CR35-45/1.9Care listed in the table below

Axis	Allowable Torque (N.m)	Allowable Inertia (kg·m <sup>2</sup> )
Axis 4	110	4.1
Axis 5	111.9	4
Axis 6	65	1.5




##### Warning

The payload must not exceed the allowable torque and inertia!

It is required to match the load according to the robot's carrying capacity. The load beyond the carrying capacity of the robot will trigger the alarm or even cause damage to robot components, thereby reducing the robot's service life.

#### 4.1.3.2 Maximum payload diagram

The center-of-gravity position of the load is determined by the distance between the load center and the flange surface, where  $L_{xy}$  represents the distance between the load center and the axis A6 and  $L_z$  represents the distance between the load center and the flange mounting surface. The distance corresponding to different loads is shown in the following diagram.



#### Warning

When calculating the load weight, the weight of the end effector shall be included, and the load requirements shall be met. In addition, the system shall never exceed the maximum payload.

#### 4.1.3.3 Calculation of load and inertia

In order to achieve optimal robot performance, you must clearly confirm that the load (the weight of the end effector and workpiece) and the inertia are within the maximum allowable value. When installing the effector at the robot end, the effector's moment of inertia shall be taken into consideration.



#### Notes

Generally, with an accurate 3D model, the mass, center of mass, and inertia of the load can be obtained quickly from the 3D CAD software.

#### 4.1.3.4 Joint torque limit

Before actual application, joint torque must be taken into account in risk analysis. The following table shows the joint torque limits, which shall be observed during use. Otherwise, the robot may be damaged due to overload.

Axis	Joint Torque Limit (N.m)
1	2940
2	2940
3	762
4	411
5	194
6	102

## 4.2 Teach Pendant

Item	Item
Product Name	xPad2
Screen size	10.1"
Resolution	1,920×1,200
Trigger type	Capacitive
Dimensions	290 mm×170 mm×80 mm
Weight	About 840 g (excluding cable)
Minimum cable bending radius	50 mm
IP rating	IP54
External port	USB 3.0
Operating temperature	0°C to +45°C
Storage temperature	-25°C to +55°C
Maximum relative operating/storage humidity	90%, non-condensing, non-frost

## 4.3 Control cab

Item	Item
Product Name	xMate Control Cab Mix
Model	MCCM-20000T
Mounting method	Floor mounting and horizontal fixing
Noise	≤70 dB
IP rating	IP54
Electrical connection	Power supply Single-phase 190 VAC–240 VAC, frequency 50 Hz–60 Hz
	Average power 1 kW
	Peak power 3.5 kW
	Short-circuit current 40 A
Operating temperature	0°C to +50°C

Storage temperature		-10°C to +55°C
Maximum relative operating/storage humidity		≤80%, non-condensing, non-frost
Physical properties	Dimensions	480 mm×325 mm×360 mm (L×W×H)
	Weight	Approx. 28.4 kg
	Color	Grey & red
User port	General-purpose digital I/O	16 inputs/16 outputs (standard), maximum 80 inputs/80 outputs (with optional components)
	Safety I/O	5 safety inputs and 4 safety outputs in dual redundant channels
	Communication port	RS232 ×1 Ethernet port ×4 USB3.0 ×1
	Fieldbus	EtherCAT ×1
	Optional extended support	General-purpose digital I/O module; Analog voltage input I/O module; Analog voltage output I/O module; Analog current input I/O module; Analog current output I/O module; Quadrature encoder signal acquisition module.
	DC output power	Voltage: 24 V DC Maximum current: 2A Short-circuit protection provided

## 5 Unpacking and Installation

This section contains instructions for CR35-45/1.9Cflexible collaborative robot.

### 5.1 Installation flow chart

The installation flow chart is used to check the robot installation progress. Put a check mark in the "Completed" column when a step is finished.

Step	Operation	Completed
1. Preparation before installation		
①	Installation personnel	
②	Installation environment	
③	Installation foundation	
④	Support pillar	
2. Confirmation of enough space for installation		
3. Unpacking and handling		
①	Unpacking	
②	Checking the packing list	
③	Handling	
4. Installation of manipulator		
①	Installing the robot in place	
5. Cable connection		
①	Connecting the power and signal cables between the manipulator and the control cab	
②	Connecting the control cab with the power socket with the power cable	
③	Connecting the Teach Pendant (if required)	
6. User wires		
①	Connecting I/O signal cables (if required)	



#### Notes

The user shall provide M16 hex wrench, unpacking tools, and necessary protective equipment such as gloves.

### 5.2 Environmental conditions

Robots are intended for use in general industrial environments and under working conditions of each component as specified in 4. The following conditions shall be met:

- Install indoor to avoid exposure to sunlight.
- Keep away from dust, metal powder, oil mist, salt mist, etc.

- Keep away from flammable and corrosive liquids and gases.
- Prevent water intrusion from all directions.
- Protect from shock and vibration.
- Operate at an altitude below 1,000 m.
- Keep away from sources of electrical interference.

In addition,

- Ensure that the electrical fast transient (EFT) is below  $\pm 2$  kV.
- Make sure the electrostatic discharge (ESD) is below  $\pm 8$  kV.



#### Warning

Never place or use the robot in any explosive environment!



#### Notes

At low ambient temperature ( $<10^{\circ}\text{C}$ ), the grease (or lubricating oil) inside the reducer (or gearbox) has a high viscosity and may cause the robot to stop or operate inefficiently. In this case, it is recommended to warm up the robot and other auxiliary equipment.

The environmental conditions under which the robot is stored shall conform to the storage conditions for each component as specified in 4.

### 5.3 Unpacking


Prepare the necessary tools for unpacking according to the table below:

S/N	Tool	Quantity
1	Pry bar	1
2	Utility knife/scissors	1
3	M16 external hex wrench	1
4	Protective gloves	1

Unpacking procedures:

- 1) Step 1: Open the wooden packaging box

Put on a pair of protective gloves, use a bar to pry open the wooden packaging box, and move the wooden box upwards to separate the wooden box from the bottom pallet.




S/N	Name
1	Box
2	Bottom pallet
3	Manipulator
4	Control cab
5	Teach Pendant cardboard box

2) Step 2: Remove the packaging of the control cab and the Teach Pendant cardboard box

Move the Teach Pendant cardboard box and control cab from the bottom pallet of the wooden box to open ground. Be careful of the directions and handle gently;


Use a pair of scissors to cut off the sealing tapes of the cardboard box, open the cardboard box, and take out the Teach Pendant cable, the Teach Pendant and the robot cable under the Teach Pendant foam.



S/N	Name
1	Teach Pendant
2	EPE foam
3	Robot cables

3) Step 3: Remove the bolts that fix the manipulator

Use an external hex wrench to remove the four sets of bolts that fix the manipulator. Unscrew them and move the manipulator to a safe position.



Keep the parts properly, and handle accessories such as USB flash drive, calibration block, control cab key, and cables with care.



Warning

When removing bolts from the manipulator, three persons shall hold the robot equipment while another person conduct the removal to prevent the equipment from tilting due to unstable center of gravity, which might result in personal injury or equipment damage. Handle the manipulator carefully after removing the bolts.

## 5.4 Transportation and handling

### 5.4.1 Robot angle and force application points during transportation

To ensure stability during transportation, the orientation and angles of each axis of the robot during transportation have been predefined, as detailed in the following diagram.



The angles of all axes in the transportation orientation are as follows:

Axis 1	Axis 2	Axis 3	Axis 4	Axis 5	Axis 6
0°	0°	165°	0°	15°	90°



#### Warning

The arrows in the figure indicate the suggested locations and directions of force application on the robot during transportation. It is prohibited to apply force to other parts of the robot during transportation. Otherwise, the robot may be damaged.

### 5.4.2 Handling

- The robot and control cab are made of precision components, so they shall be protected from excessive shock and vibration during transportation.
- In order to ensure safe transportation and installation, remove all obstacles in advance to keep the passage clear.
- The environmental conditions under which the robot and control cab are handled shall conform to the storage conditions for each component as specified in 4.



#### DANGER

All power of the robot shall be turned off during transportation.


#### 5.4.2.1 General description

In principle, the lifting equipment such as travelling crane shall be used during handling. Crane and forklift shall be operated by professional with operational qualification, otherwise, there may be accidents such as personal injury, equipment damage and so on.

#### 5.4.2.2 Tilt risk

If the robot is not fixed on any base and stays stationary, it is unstable and any movement operation may cause its center of gravity to shift or tilt, or even result in rollover; The transportation orientation is the most stable orientation for the robot. Do not change it before the robot is fixed on the base.

### 5.4.2.3 Transportation dimensions



### 5.4.2.4 Crane

The weight of CR35-45/1.9C series manipulator is approximately 170 kg. Please choose a wire rope or sling with sufficient strength.

The weight of the control cab is approximately 28.4 kg. Please choose a wire rope or sling with sufficient strength (recommended sling with bearing capacity of 400 kg–1 T).

Avoid excessive vibration and collision during handling, otherwise, there may be influence on the performance of precision equipment.

When transporting the manipulator, use steel wire ropes or slings. It is recommended to use slings or protected steel wire ropes as the lifting ropes to prevent the lifting ropes from damaging the paint finish of the manipulator. Please refer to the diagram below for the specific lifting method.



#### Warning

The weight of CR35-45/1.9C series manipulator is approximately 180 kg. Please be sure to use a lifting rope with a bearing strength of 1T or more. Lifting the robot at any position other than the recommended position may cause the robot to tip over and result in the serious damage or injury!




#### Warning

In any case, no person is allowed to stand below the place where the robot or control cab is lifted.

**DANGER**

Be sure to turn off all power supplies, sources of hydraulic pressure and air sources to the robot while transporting, disconnect the power supply of the control cab, and close and lock the sheet metal door.



## 5.5 Installation

### 5.5.1 Inspection before installation

Personnel who install and operate the robot must have the necessary knowledge for the installation, maintenance, and repair of mechanical and electronic equipment, and must comply with all the relevant national and local regulations.

Check the prerequisites for installation:

S/N	Operation
1	Visually inspect the robot to confirm that it is not damaged.
2	Make sure that the intended operating conditions of the robot conform to those specified in this section.
3	Make sure that the installation conditions comply with the requirements.
4	Make sure that the storage conditions comply with the requirements if the robot is not installed immediately.
5	When these prerequisites are met, install the robot as described in the next section.

### 5.5.2 Installation of robot and control cab

The following precautions shall be noted during installation of the control cab:

To ensure effective heat dissipation (preventing overheating of the control system) and reserve operational space for the control cab, when placing the MCCM, please ensure a minimum clearance of 300 mm on the right side and 120 mm at the rear. If the front door of the control cab does not need to be opened, a minimum clearance of 120 mm must still be maintained.

- A wiring space shall be reserved at the relay cable interface on the right panel of the control cab. The bending radius of the power relay cable shall not be less than 100 mm, and the bending radius of the signal relay cable shall not be less than 60 mm.
- A Teach Pendant cable interface is provided on the front panel of the control cab, and the bending radius of the Teach Pendant cable shall not be less than 80 mm.



### DANGER

The control cab contains high-voltage components. Unauthorized personnel are strictly prohibited from opening the cab enclosure. Otherwise, severe or even fatal injuries may occur!


#### 5.5.2.1 Installation and fixing

Mounting Parts	Specifications	Bracket installation
Hexagon socket head cap screw	M16×45 (Grade 12.9) ×4	√
Mounting seat	Mounting plate thickness: 30 mm or above	√

Note:


- No insulating layer is allowed between the fixing plate/mounting seat and the manipulator/concrete;
- "√" indicates that the item is required for the installation.
- The fixing rigidity of the mounting bracket shall not be lower than that of the robot fixing plate and the foundation.

The robot fixing modes and parameters are shown in the figure below:



Put pins in the reserved cylindrical pin holes for accurate positioning. Then use four M16×45 hexagon socket head cap screws (strength grade 12.9) to fix the robot's base on the bracket.



The control cab fixing modes and parameters are shown in the figure below:



There are  $4 \times M8$  threaded holes with a depth of 8 mm at the bottom of the control cab, which can be fixed according to the on-site operating environment.

#### 5.5.2.2 Supporting reaction force of the robot

After the robot is installed, its mounting base will generate a large support reaction force due to the static force and dynamic force of the robot, as shown in the figure below. Therefore, the robot base must be able to bear this force.



Force	Maximum	Unit
F <sub>xy</sub>	2989	N
F <sub>z</sub>	2817.5	N
M <sub>xy</sub>	4427.64	N·m
M <sub>z</sub>	2638.16	N·m




## Notes

The above force and torque are the limit values that may appear during the motion of the robot. The limit values rarely occur and cannot be reached at the same time.

### 5.5.3 Flange

To ensure the accurate positioning of the EOAT, the reserved  $\Phi 8$  pin holes shall be used. There are six M8 threaded holes on the end flange of the robot to attach the EOAT to the flange. The M8 screws must be tightened with a torque of 38 N.m. See the figure below for the detailed dimensions.




## Warning

- The EOAT shall be properly secured in place to prevent its range of motion from overlapping with the robot's working space.
- The length of the M8 screws on the installed EOAT shall not exceed the length of thread indicated in the figure to avoid any irreparable damage.
- The EOAT shall operate safely without any detached parts to cause dangers.

## 6 Electrical connection

### 6.1 Control cab port


#### 6.1.1 Panel port




The panel is described as follows:

S/N	Description
①	Power indicator: After pressing the power button to start the system, the power indicator enters the working state (white light); press the power button again to shut down the system, and the power indicator turns off.
②	Power button (marked as "POWER"): Once pressed, the system starts, and the ring indicator lights up (white light). If pressed again, power supply of the system is cut off.
③	Emergency stop button: The robot will be shut down immediately when it is pressed.
④	Door lock
⑤	Teach Pendant port (marked as "TP"): Used for connecting the xPad2 Teach Pendant.
⑥	User cable outlet (marked as "I/O")
⑦	Signal relay cable port (marked as "SIGNAL"): Used for connecting the robot's signal relay cable.
⑧	Power relay cable port (marked as "MOTOR"): Used for connecting the robot's power relay cable.
⑨	Control cab power cable port (marked as "POWER")

Enlarged view of port at side of the panel



### 6.1.2 Internal port



1	<b>RJ45 debugging port:</b> Used by after-sales personnel for EACT debugging inside the servo system.
2	<b>Type-C debugging port:</b> Used by after-sales personnel for servo debugging.
3	<b>Safety I/O wiring terminal</b>

4	<b>General-purpose I/O wiring terminal</b>
5	<b>Optional module port:</b> Used for optional function expansion.
6	<b>Ethernet port:</b> Used for external Profinet or EtherNet/IP bus (optional).
7	<b>HMI port:</b> Used for connecting external client to HMI.
8	<b>Visual port:</b> Used for connecting an industrial camera with an RJ45 port.
9	<b>EtherCAT</b> device expansion network port: Used for expanding the devices or I/O module of the EtherCAT port.
10	<b>RS232/RS485</b> (serial communication port): Used for communication and debugging.
11	<b>USB port:</b> Used for internal debugging and data import/export.



### DANGER


- The control cab contains high-voltage components, so non-professionals shall not open the control cab door with electricity.
- Before opening the front door of control cab for wiring, the user shall power off the control cab. After wiring, he/she shall close the front door before powering on the control cab.
- Live operation/hot-line job may cause damage to the components, even severe or fatal personal injuries.



### Notes

The safety I/O port and general-purpose digital I/O port use spring pluggable terminals. When the plugging is not smooth, it is required to check the terminal crimping and avoid brute plugging.

### 6.1.2.1 Description of safety I/O ports




Each group of safety input or safety output signals is dual-channel redundant, so each group contains two inputs/outputs, namely "Loop 1" and "Loop 2", with a total of 4 connecting terminals. Definition of pins:

Terminal No.	Function Definition	Explanation
1	Safety gate_24V1	Safety gate loop 1, short-circuited when not in use
2	Safety gate_Input1	
3	Safety gate_24V2	Safety gate loop 2, short-circuited when not in use
4	Safety gate_Input2	
5	External emergency stop_24V1	External emergency stop loop 1, short-circuited when not in use
6	External emergency stop_Input1	
7	External emergency stop_24V2	External emergency stop loop 2, short-circuited when not in use
8	External emergency stop_Input2	
9	Emergency stop 1	Robot emergency stop output circuit 1, normally closed when emergency stop is not triggered
10	Emergency stop 1	
11	Emergency stop 2	Robot emergency stop output circuit 2, normally closed when emergency stop is not triggered
12	Emergency stop 2	
13	Remote power on/off 1_24V1	Wiring point for remote power on/off of the robot control cab, active at negedge (this function needs to be enabled on the Teach Pendant)
14	Remote power on/off 1_Input1	
15	Remote power on/off 2_24V2	Wiring point for remote power on/off of the robot control cab, active at a


16	Remote power on/off 2_Input2	high level and with priority higher than the negedge on/off signal (this function needs to be enabled on the Teach Pendant)
17	STO1+	Reserved point position
18	STO1-	
19	STO2+	
20	STO2-	
21-24	24 V	24 V guest power, supply current lower than 5 A
27-30	0 V	
31-35	Passive short contact 1	The five terminals are conducted to each other and can be used as short contacts
36-40	Passive short contact 2	The five terminals are conducted to each other and can be used as short contacts

- External emergency stop wiring diagram




The user can connect emergency stop buttons or emergency stop handles through this interface. For example, when using the emergency stop button, as the interface is active, simply connect the input/output circuit of the emergency stop switch to the external emergency stop interface, as shown in the figure above.

- Safety gate wiring diagram



The user can connect safety gate devices (photoelectric switches/travel switches/safety light curtains, etc.) through this port. For example, when using a safety light curtain, as the interface is active, simply connect the switch input/output circuit to the safety gate interface, as shown in the figure above.

- Description of safety input loop ports




The principle of both loops is the same, and 24 VDC signals are supported.

When wiring, if the safety signals 1AP and 1AN, 1BP and 1BN are short-circuited at the same time, the safety input is valid, and if they are open-circuited at the same time, the safety input is invalid, and the others are abnormal state.

Item	Parameter
Input current	$\leq 50$ mA per loop
Wire resistance	$\leq 15$ $\Omega$ per loop
Quantity	5

- Description of safety output loop ports




## Notes

We highly recommend connecting a freewheeling diode in parallel at both ends of the inductive load.

The safety output loop uses MOSFET output and re-collects the voltage of the MOSFET. The principle of two loops is the same, and 24 VDC signals are supported. When the output signal is valid, a voltage of 24 VDC is generated between the SDOxP and SDOxN.

Item	Parameter
Type	Semiconductor output
Voltage range	High level: 20 VDC to 30 VDC; low level: -5 VDC to +5 VDC
Drive current	100 mA per circuit
Quantity	4

#### 6.1.2.2 Description of general-purpose digital I/O ports



The control cab is equipped with 16 general-purpose digital inputs and 16 general-purpose digital outputs as standard, with pin definition as follows:

Terminal No.	Function Definition	Explanation
COM0	Common port	DI-0~7 power, provided on site
	Common port	
DI-0	DI0	Custom
DI-1	DI1	Custom
DI-2	DI2	Custom
DI-3	DI3	Custom
DI-4	DI4	Custom
DI-5	DI5	Custom
DI-6	DI6	Custom
DI-7	DI7	Custom
COM0	Common port	DI-8~15 power, provided on site
	Common port	
DI-8	DI8	Custom
DI-9	DI9	Custom
DI-10	DI10	Custom
DI-11	DI11	Custom
DI-12	DI12	Custom
DI-13	DI13	Custom
DI-14	DI14	Custom

DI-15	DI15	Custom
GND	Common port	DO power - GND (negative pole), provided on site
	Common port	
D0-0	DO0	Custom
D0-1	DO1	Custom
D0-2	DO2	Custom
D0-3	DO3	Custom
D0-4	DO4	Custom
D0-5	DO5	Custom
D0-6	DO6	Custom
D0-7	DO7	Custom
24V	Common port	DO power - 24 V (positive pole), provided on site
	Common port	
D0-8	DO8	Custom
D0-9	DO9	Custom
D0-10	DO10	Custom
D0-11	DO11	Custom
D0-12	DO12	Custom
D0-13	DO13	Custom
D0-14	DO14	Custom
D0-15	DO15	Custom


● Description of general-purpose DI ports

The 16 digital inputs include drain and source type. When the input is active high (sink), the PNP level signals are available, and when the input is active low (source), the NPN type level signals are available:


Item	Parameter
Input voltage range	0 VDC to 28 VDC
Turn-on voltage	Common port 0 VDC: high input, 18 VDC to 28 VDC Common port 24 VDC: low input, 0 VDC to 5 VDC
Turn-off voltage	Common port 0 VDC: high input, 0 VDC to 5 VDC Common port 24 VDC: low input, 19 VDC to 24 VDC
Input impedance	> 6.8 kΩ
Isolation method	Optocoupler isolation

The electrical principles in the two modes are shown below.

When the common port is 0 VDC, the PNP input signals are available, as shown below:



When the common port is 24 VDC, the NPN input signals are available, as shown below:



- Description of general-purpose DO ports

The 16 digital outputs include drain and source type, which can be configured to active high and active low, and the output parameters are as follows:


Item	Parameter
Load voltage range	$\leq 28$ VDC
Rated load current	Max. 500 mA (continuous load current cannot exceed the maximum)
Output impedance	$\leq 2.5 \Omega$
Output short circuit protection	Typical 1.8 A
Drain current	$\leq 5 \mu A$
Maximum I/O signal response frequency	1 kHz
Isolation method	Optocoupler isolation

When connecting the digital output port, both for sinking output and sourcing output, it is necessary to connect the 24 V and GND ports to the 24 V power supply and ground respectively.


The electrical principles in the two modes are shown below.

The output is active low. First, connect the 24 V (common port) to the positive pole of the

24 V power supply, and the GND (common port) to the negative pole of the 24 V power supply. Meanwhile, connect the robot's GND port to the user's GND port, as shown below.



The output is active high. First, connect the 24 V (common port) to the positive pole of the 24 V power supply, and the GND (common port) to the negative pole of the 24 V power supply. Meanwhile, connect the robot's GND port to the user's GND port, as shown below.




#### Notes

1. We highly recommend connecting a freewheeling diode in parallel at both ends of inductive loads.
2. For the application configuration of the digital I/O port in HMI, refer to "7.4 Application configuration of general-purpose digital I/O port"!

## 6.2 Band-type brake release

To make it easy for debugging and maintenance, the CR35-45/1.9C series robot is equipped with a band-type brake release button on the base electrical installation cover, which shall be used as follows:

- Unscrew the six M4 hex socket pan head screws from the band-type brake release cover;
- Open the band-type brake release cover;
- Press and hold the enabling button "EN" and the sequential number button corresponding to the axis to be released to release the band-type brake;
- Install the band-type brake release cover and tighten the screws to a torque of 1 N·m.



S/N	Description
1	Band-type brake release cover
2	Enabling button
3	Brake buttons for each axis




### DANGER

The band-type brake release operation work must be carried out by certified operators or qualified personnel;


Before releasing the band-type brakes of the Axes 2 and 3, make sure to fix the lower arm and upper arm by using a tool such as a traveling crane. Otherwise, personal injury or equipment damage may occur due to falling of the lower arm and upper arm that lose braking function after the band-type brakes are released.

## 6.3 Description of EOAT I/O ports

The robot's end flange is equipped with a tool I/O port, as shown in the figure—① indicates the tool I/O port.



The EOAT I/O port is an electrical expansion port for end effector and is an M8 circular connector for M8-FS-8CON-PVC-2.0 industrial cables.



S/N	Cable Color	Definition
1	White	AI_0/RS485+
2	Brown	AI_1/RS485-
3	Green	DI_1
4	Yellow	DI_0
5	Gray	0V/12V/24V
6	Pink	DO_1
7	Blue	DO_0
8	Red	GND

### 6.3.1 Special-purpose EOAT I/O

A special-purpose gripper is optional for the robot as the end effector, with the electrical and special-purpose communication ports integrated into the connector.

### 6.3.2 EOAT power output

When the user uses the gripper and sensor as robot EOAT, the M8 connector provides power with electrical specifications as follows:

	Minimum	Typical	Maximum	Unit
EOAT supply voltage	12	24	24.8	V
EOAT supply current	—	1	2	A



## Warning

For the EOAT power supply, the peak current is 2 A, and the peak time does not exceed 1s.



## Notes

We highly recommend connecting a freewheeling diode in parallel at both ends of the inductive load.


### 6.3.3 EOAT digital outputs

There are 2 EOAT digital outputs, which can be configured to NPN or PNP through HMI. In PNP mode, the EOAT power output shall be valid, and the PNP output level shall be consistent with the EOAT supply voltage.

The electrical specifications of the digital output NPN mode are as follows:

Item	Minimum	Typical	Maximum	Unit
Operating voltage	-0.5	-	26	V
Sink current	0	-	150	mA
Voltage in output active (sink current: 200 mA)	0	0.05	0.2	V


Wiring diagram in digital output NPN mode



The electrical specifications of the digital output PNP mode are as follows:

Item	Minimum	Typical	Maximum	Unit
Operating voltage	0	-	26	V
Sink current	0	-	150	mA
Voltage in output active (source current: 200 mA)	0	12/24	26	V

Wiring diagram in digital output PNP mode



## Warning

The digital outputs in the EOAT are not current-limited. Overriding the specifications can cause permanent damage.



## Notes


We highly recommend connecting a freewheeling diode in parallel at both ends of the inductive load.

## 6.3.4 EOAT digital inputs

There are 2 EOAT digital inputs, which are only available for NPN mode, with weak pull-high function. The digital inputs are always invalid in hover state, with electrical characteristics as follows:

Item	Minimum	Typical	Maximum	Unit
Input voltage	0	-	26	V
Logical active level	0	-	3	V
Logical inactive level	8	-	26	V
Input resistance	-	47	-	kΩ

Diagram of connecting 1 simple switch to the user port:




### 6.3.5 EOAT analog inputs

The EOAT analog inputs are available for both voltage and current modes through the HMI.

The parameters of analog voltage inputs are as follows:

Item	Minimum	Typical	Maximum	Unit
Input voltage in voltage mode	0	-	26	V
Input resistance in voltage mode	-	22.4	-	kΩ
Resolution	-	12	-	bit


Wiring diagram of analog voltage input port



The parameters of analog current inputs are as follows:

Item	Minimum	Typical	Maximum	Unit
Input current in current mode	4	-	20	mA
Input voltage in current mode	0	-	6	V
Input resistance in current mode		240		Ω
Resolution	-	12	-	bit

Wiring diagram of analog current input port



### 6.3.6 EOAT communication


The EOAT supports RS485 bus communication and follows the Modbus communication protocol.

The communication baud rate includes 9600, 19200, 38400, 57600, 115200, etc.

The EOAT communication port supports Modbus transparent transmission, the EtherCAT communication is adopted between the IPC and the EOAT and the message transmission delay does not exceed 3 ms when the EOAT performs RS485 communication with the end effector.

## 6.4 Connection system

A complete CR35-45/1.9C electrical connection system is shown in the figure below:



S/N	Name
①	Manipulator
②	Control cab
③	Teach Pendant
④	Signal relay cable
⑤	Power relay cable
⑥	Controller power cable
⑦*	Personal computer with a network cable port

\*Note: ⑦ and ③ share the same electrical port, so they cannot be connected at the same time. The personal computer with a network cable port is usually used for debugging, the practical application is connected in the same way of Teach Pendant.




### DANGER

Before wiring, it is required to power off the controller and related devices and put the warning symbol (e.g. do not turn on the power). Wiring under power-on conditions is extremely dangerous and may cause electric shock or malfunction of the robot system.

#### 6.4.1 Connection of the Teach Pendant

When mating the Teach Pendant connector, please follow the method shown in the figure: align the triangle on the cab-side connector with the triangle on the Teach Pendant-side connector before inserting, to avoid damaging the connector pins due to misalignment.




#### 6.4.2 Connection of the manipulator

There are two connecting wires between the control cab and the manipulator, namely the power relay cable and the signal relay cable, which are 6 m flexible cables as standard. The mass of the power and signal relay cables is about 4.75 kg and 0.85 kg, respectively.



Connect the socket marked with the "MOTOR" on the side of the control cab with the socket marked with ① at the manipulator base using a power relay cable, and connect the socket marked with the "SIGNAL" on the side of the control cab with the socket marked with ② at the manipulator base using a signal relay cable.



#### 6.4.3 Connection of the control cab power supply

The control cab is provided with a single-phase AC power supply with parameters as shown in 4.3. The user shall provide a power supply that meets the relevant parameter requirements. The robot is supplied with a 6 m power cable as standard, with a plug (on one end) that matches the socket marked "POWER" on the side of the control cab and a 16 A grounding single-phase three-pin plug (on the other).



##### Warning

For overcurrent protection of the control cab power supply, the user shall cautiously choose a suitable overcurrent protector according to the rated power of the purchased control cab.

The user shall ensure good grounding.



##### Notes

All connectors shall be plugged in carefully and gently. If difficult, you shall check whether the pins in the connector are skewed, and if any abnormalities are found, they shall be corrected to avoid damage to the connectors.

#### 6.4.4 Custom wiring

The custom wiring is suitable for the following:


- Custom I/O signals (including safety I/O and general-purpose digital I/O)
- Custom network/communication signals




##### Warning

The wiring must be carried out by the certified workers or qualified personnel with relevant knowledge. Otherwise, it may result in personal injury or equipment malfunction.

The MCCM has an IP54 rating, and there is no interface window on the cabinet. The cables for custom I/O signals (including safety I/O and general-purpose I/O) and network/communication signals need to be routed through the foam with pre-opened holes on the right side of the cabinet. Please select the holes with a suitable diameter for the cables to go through, and take measures to protect the outlets after wiring. The pre-opened holes in the foam are as shown in figure:



The diameter of the pre-opened holes in the foam is shown below




When wiring the safety I/O and general-purpose I/O, there are cable tying brackets reserved at the internal outlet of the control cab. The cables must be secured with cable ties to keep the harnesses inside the cab neat and tight.

#### 6.4.5 Grounding instructions

The user shall properly ground the manipulator and the control cab with terminals according to the actual on-site situations and the available space to achieve D-type grounding (the grounding resistance shall be less than  $100 \Omega$ ).

The control cab can be grounded by the grounding terminal of the power cable, and the grounding position of the manipulator is shown in the figure below.



## 7 Quick Operation

### 7.1 Power on

After completing the above wiring, you shall check and confirm the following contents before powering on:

- The power connector of the control cab is well plugged.
- The control cab is properly connected with the robot.
- The control cab is properly connected with the Teach Pendant.
- The power switch of the control cab is in the off state when power supply is not turned on.
- The emergency stop switch of the Teach Pendant is in the release state.
- The power supply of the control cab provided by the user meets the requirements and operates normally.
- The user ensures that the robot does not collide with the surrounding personnel or equipment.
- The control cab is firmly fixed.
- The manipulator is firmly fixed.

After confirming without error, press the self-reset button marked "POWER" on the panel of the control cab, the white power indicator on the control cab door will be on, and the system will be powered on and started normally.

If everything is normal, the system will display a welcome interface on the Teach Pendant after startup. If an alarm occurs after the startup or the system cannot be started, you shall:

- Turn off the power switch and recheck the wiring.
- Contact the technical support.

### 7.2 Confirmation of the emergency stop

After startup, press the emergency stop button on the Teach Pendant to check if an emergency stop alarm of the control system is triggered. Then release the emergency stop button to check if the emergency stop alarm is successfully cleared and the system returns to normal.

After confirming the normal performance of the emergency stop, you can conduct configuration or programming on the robot.

### 7.3 Programming and usage

For more information about the usage, programming, and parameter settings of the robot operating system, refer to the xCore Robot Control System User Manual.


## 7.4 Application configuration of general-purpose digital I/O port

To configure the general digital I/O ports, a Teach Pendant is required, provided that the Teach Pendant has been correctly connected to the control cab and the communication is normal.

On the Teach Pendant interface, click "Communication" to enter the communication interface, then click "I/O Devices" again to access the I/O device configuration interface.


Two I/O sequences (0 and 1) will be displayed on this interface; select I/O sequence 1.

After selection, click the icon indicated by the red arrow in the figure below, as shown in the following figure:



Access the device editing interface, as shown in the figure below:

At the position marked by the red box, you can configure the output I/O type: select PNP for outputting high-level signals and NPN for outputting low-level signals.



Click "Status Monitoring" in the top right corner of the figure above to access the status monitoring interface, as shown in the figure below:

16 channels of input and 16 channels of output are monitored. When an input signal is received, the input switch will open automatically.

When an output signal is required, the switch must be manually turned on.

## 8 Maintenance

### 8.1 Introduction

Please read the "Maintenance safety" section, this manual, and other related documents carefully to gain a full understanding of the safe maintenance methods before maintenance.

### 8.2 Maintenance safety



#### Warning

- The maintenance procedures shall be followed strictly to avoid random disassembly.
- The maintenance shall only be performed by designated professionals.
- Without accepting training, you shall stay away from the robot when it is powered on. Also, you shall do not enter the robot's range of motion. Even if a powered-on robot seems to stop, it may move accidentally and cause serious safety problems.
- It is required to confirm the action of the robot after replacing the parts outside the safety fence. Otherwise, the robot may perform unexpected actions and cause serious safety problems.
- Before robot's normal operation, the emergency stop switch and the safety fence switch shall function properly. Otherwise, the safety functions cannot be guaranteed in the event of an emergency, and serious injury or damage may occur, which is extremely dangerous.

### 8.3 Maintenance schedule

The robot must be maintained regularly to ensure high performance over a long period of time. The maintenance personnel must prepare a maintenance schedule and implement such schedule strictly.

### 8.4 Inspection

S/N	Item	Position	Interval				
			Daily	1 month	3 months	6 months	1 year
1	Check the appearance for damage	Robot appearance					
		External cables					
2	Check the control cab and robot connector for looseness	Control cab					
		Manipulator					
3	Encoder battery	Replace the battery if a low-battery error warning appears when the software starts up or once every 1.5 years.					

## Cleaning

### 8.5 Lubrication



#### Notes

Injection of lubricating oil requires professional person to operate with professional tools! If there is any problem occurred in the adjustment, please call us!



#### Warning

Avoid grease depletion. Once the grease is depleted, abnormal noise may occur and the mechanical transmission components may be damaged, thus affecting the performance and use of the robot;

Be extremely careful when refilling the grease. Once grease enters into your eyes or mouth or adheres to your skin, treat according to the following instructions:

When grease enters into your eyes: Flush your eyes with running water and get medical help;

When grease enters into your mouth: If swallowed, get medical help immediately.

Otherwise, wash thoroughly with clean water;

When grease adheres to your skin: Clean it up with water and soap.

#### 8.5.1 Oil refilling mode

It is recommended that customers use a manual pump to refill oil into the robot. The commonly used oil pump is shown in the figure below:



When using a manual pump, the refill speed shall not be too fast (do not exceed 300 g/min). The pump pressure is set below 0.03 Mpa. To prevent the internal pressure of the reducer from being too high due to the high speed of oil refill, it is best to keep the movement of pressing down at once per second during manual refill.

In addition, when using a manual pump, in order to ensure the smooth removal of used oil

inside the reducer, it is recommended that after a period of oil injection, stop for a period of time, wait until the outlet does not discharge oil and then continue to inject oil.



#### Notes

Open the oil discharge outlet before refilling oil, that the speed of refilling oil is too fast will cause the instantaneous internal pressure of reducer to go high, grease with high pressure may cause damage to oil seals, grease entering the motor may cause the module to leak oil.



#### Warning

The robot shall run for 10 to 20 minutes before detecting the oil level.

After the robot runs, the temperature of the motor and gear is very high, be careful of scald.

Turn off all power, hydraulic and barometric sources.

Because the temperature of oil in the gearbox is very high, the pressure inside may increase.

When opening the plug, the oil inside may be ejected. Therefore, the operator must wear protective glasses and gloves when replacing or discharging lubricating oil!

### 8.5.2 Reducer lubrication

In order to exert the performance of the robot adequately, use the appropriate amount of grease of the specified type at the corresponding position. Apply grease in each axis as shown in the following table:


Axis no.	Type of Grease	Maintenance Cycle
Axis 1	Molywhite RE N0.00	20,000 hours or 4 years
Axis 2	No lubrication	/
Axis 3	No lubrication	/
Axis 4	No lubrication	/
Axis 5	No lubrication	/
Axis 6	No lubrication	/



#### Notes

The robot has been filled with specified amount of grease when it leaves the factory, please don't mix with other greases, otherwise, it may cause breakdown of reducer after it is used for a period of time.

### 8.5.3 Axis 1 reducer lubrication




	Description
1	Axis 1 oil filling port
2	Axis 1 oil outlet

The steps for replacing the grease of the axis 1 reducer are as follows:

- 1) Adjust all axes to the zero position;
- 2) Remove plugs from the oil filling port and oil outlet for axis 1;
- 3) Install the Rc1/8 nozzle at the oil filling port;
- 4) Refill oil from the oil filling port with an oil gun. The refill speed shall not exceed 300 g/min, until the old oil is completely emptied and the new oil flows out. When the grease replacement is completed, apply the Three Bond 1215 sealant to the thread;
- 5) Before installing the plug in the oil outlet, run axis 1 for 20 min at the speed of V1000 50% in the motion range of  $\pm 80^\circ$ , discharge redundant grease and gas;
- 6) Wipe the redundant grease out of the oil outlet with a cloth, and install the plug at the oil outlet. Apply the Three Bond 1215 sealant to the screw thread of the plug.

### 8.5.4 Axis 2 reducer lubrication



	Description
1	Axis 2 oil filling port
2	Axis 2 oil outlet

The steps for replacing the grease of the axis 2 reducer are as follows:

- 7) Adjust all axes to the zero position;
- 8) Remove plugs from the oil filling port and oil outlet;
- 9) Install the Rc1/8 nozzle at the oil filling port;
- 10) Refill oil from the oil filling port with an oil gun. The refill speed shall not exceed 300 g/min, until the old oil is completely emptied and the new oil flows out. When the grease replacement is completed, install the plug at the oil filling port, and apply the Three Bond 1215 sealant to the thread;
- 11) Before installing the plug in the oil outlet, run axis 2 for 20 min at the speed of V1000 50% in the motion range of  $\pm 90^\circ$ , discharge redundant grease and gas;
- 12) Wipe the redundant grease out of the oil outlet with a cloth, and install the plug at the oil outlet. Apply the Three Bond 1215 sealant to the screw thread of the plug.

## 8.6 Battery replacement

### 8.6.1 Safety risks with batteries

Under normal conditions of use, the electrode materials and liquid electrolytes in the batteries will not be exposed to the outside provided that the battery integrity is maintained. Risk of exposure only occurs in the case of abuse (mechanical, thermal, electrical), which may lead to the activation of safety valves and/or the rupture of the battery containers. Electrolyte leakage, electrode materials reaction with moisture/water or battery vent/explosion/fire may follow, depending upon the circumstances.



#### Warning

Pay particular attention to the use of batteries. Avoid the improper use described below to prevent potential heating, liquid leakage, explosion, and fire.

Improper use includes: attempting to charge, deformation under compression, disassembling, short circuit, improper battery connection, heating, placing in fire, soldering battery terminals, and forced discharge.

For disposal of batteries, refer to relevant national and local laws and regulations or consult a professional company. Note that even used batteries can cause a short circuit when they come into contact with other metals or battery terminals and result in danger.

### 8.6.2 Battery replacement

- 1) Status confirmation:

Only when the robot stays stationary and the power is OFF can you replace the battery. Check the status before operation.



#### Warning

A mechanical zero inspection shall be performed upon the completion of battery

replacement on the robot in any status.

2) Preparation of tools: Prepare replacement tools according to the table below.

S/N	Tool	Specifications	Quantity
1	Side-cutting pliers		1
2	Hex wrench	3	1
3	Nylon ties	3x100mm	2

Replacement procedures:



Step 1: Remove the external cables connected to all electrical interfaces on the robot base.



Warning

During the battery replacement, take necessary precautions to prevent others from switching on the system power supply.

Step 2: Remove the fixing screws from the electrical installation board of the base and pull out the electrical installation board;



S/N	Name	Specifications	Quantity
1	Hexagon socket head cap screw	M5X12	6
2	Electrical installation board		1
3	Battery connector 1		1
4	Battery connector 2		1
5	Tie	3x100mm	2
6	Battery connector 3		1

Step 3: Cut off the ties that fix the old battery pack;

Step 4: Bundle the new battery onto the cable board with ties;

Step 5: First disconnect the old battery connector 1 and connect the new battery connector 1;

Step 6: Then disconnect the battery connector 2 and connect the new battery connector 2;  
(Note: Battery connector 1 and connector 2 must not be disconnected simultaneously.)

Step 5: Connect the black battery connector 3 to the board's J3 interface, as shown in the figure;

Step 6: Secure the cables and connectors properly;

Step 6: Install the electrical installation board back.



#### Notes

For circumstances where the zero point is lost due to failure to follow the above procedures, refer to 9.4 for zero calibration.

## 8.7 Cleaning



#### Warning

Improperly using the liquid detergents or incorrectly turning off the power supply may cause electric shock and result in serious injury or death.



#### Warning

The cleaning shall be performed only after the robot is completely powered off.

The robot shall not be cleaned with liquid detergents.

The robot shall not be powered on when it is wet.

The following instructions shall be observed when cleaning the robot:

Clean the robot only by trained users.

Do not clean the robot with any chemical solvents, but use a damp cloth that has been wrung out.

Do not apply excessive force to the manipulator during cleaning. Always hold the part that is manually cleaned by hands to avoid overloading the manipulator and causing any damage.

Power on the robot only after all the surfaces are completely dry.



#### Warning

Improper cleaning may damage the robot.

## 9 Zero calibration

This section describes the zero calibration. Only the calibration tools described in this section shall be used during calibration.

### 9.1 What is a mechanical zero?

The robot is pre-defined with an initial orientation during its design, in which the angle of each joint is zero. From a mechanical viewpoint, the zero orientation is the orientation where a specific angle is formed between adjacent links. From a software viewpoint, since the robot uses the encoder to record the joint angle, the zero orientation refers to the robot's orientation when the servo motor rotates to a specific encoder value. Therefore, the mechanical zero can be explained in two ways:

- From the perspective of the observer, the mechanical zero is the robot's orientation when each joint of the robot moves to a specific position.
- From the perspective of the control system, the mechanical zero is a combination of encoder values.

### 9.2 What is zero calibration?

The zero is a point of reference for the robot coordinate system, which is essential for the robot to determine its own position. To maximize the absolute positioning accuracy and make the link system properly respond to the position and speed instructions from the control system, a zero calibration must be performed on the robot to bring the mechanical zero as close to the algorithm zero as possible.

More generally, zero calibration is the process of using the pre-designed positioning devices on the mechanical arm body to rotate the joints of the robot to a certain angle, and notifying the control system to record the value of each joint motor encoder.

### 9.3 When is zero calibration required?

A zero calibration must be performed using dedicated calibration tools in the following circumstances:

- The mechanical system parts such as motors and reducers are replaced.
- A violent collision occurs.
- The robot joint is moved by external force with system powering off.


### 9.4 Zero calibration procedures

CR35-45/1.9Crobot. Only one axis can be calibrated at a time, and the specific process is as follows.

Step 1: Calibrate the axis 1.

Rotate the axis 1 slowly until the calibration pin ② is aligned with the calibration slot, then insert it into the keyway towards the direction indicated in the figure below and with

a special calibration tool. If it cannot be inserted into the keyway of the upper and lower links at the same time, continue to rotate the axis 1 slowly until it is inserted properly. At this time, it is considered that the mechanical zero calibration of axis 1 is finished.




Step 2: Calibrate axes 2, 3, 5, and 6.

Calibrate according to step 1.

Step 3: Calibrate the axis 4.

Calibrate the axis 4 according to step 1, but note that the direction of the special calibration tool is opposite to that of step 1.



#### Warning

After the mechanical zero calibration is finished, the special calibration tool must be removed from the corresponding calibration keyway, and the manipulator status must be inspected to prevent accidents.

## 10 Safety Manual

### 10.1 Stop time and stop distance

The stop time is the time from the moment the stop signal is generated to the moment when all joints stop working.

The stop distance is the angle that passes from the moment the stop signal is generated to the moment when all joints stop working.


Data on speed, reach, and load combinations for different stop types (stop1) for axes 1, 2, and 3 that travel longer distances is provided.

The test of axis 1 is conducted by horizontal movement, that is, the rotation axis is perpendicular to the ground. During the test process of axis 2 and axis 3, the robot follows a vertical trajectory, with the rotation axis parallel to the ground, and performs a stop operation when the robot moves downward.


### 10.2 Test data

Stop distance of axis 1:


Stop distance at 33% maximum reach under different speeds and loads.



Stop distance at 66% maximum reach under different speeds and loads.




Stop distance at 100% maximum reach under different speeds and loads.




Stop time of axis 1:


Stop time at 33% maximum reach under different speeds and loads.



Stop time at 66% maximum reach under different speeds and loads.




Stop time at 100% maximum reach under different speeds and loads.




Stop distance of axis 2:


Stop distance at 33% maximum reach under different speeds and loads.



Stop distance at 66% maximum reach under different speeds and loads.




Stop distance at 100% maximum reach under different speeds and loads.




Stop time of axis 2:


Stop time at 33% maximum reach under different speeds and loads.



Stop time at 66% maximum reach under different speeds and loads.




Stop time at 100% maximum reach under different speeds and loads.




Stop distance of axis 3:

Stop distance at 100% maximum reach under different speeds and loads.



Stop time of axis 3:

Stop time at 100% maximum reach under different speeds and loads.



## 11 Decommissioning

### 11.1 Robot decommissioning

The decommissioning, storage, and disposal of the robot must be performed in compliance with relevant national laws, regulations, and standards.

### 11.2 Recycling

Contact us for the recycling of robot.

## 12 Revision history

Version	Date	Revision history
A	September 20, 2025	First release
B	January 5, 2026	First revision, adding stop distance and stop time



# ROKAE



ROKAE

---

**400-010-8700**

[www.rokae.com](http://www.rokae.com)

[sales@rokae.com](mailto:sales@rokae.com)